

Parts Included:

Plastic Anchors
Mounting Screws
Mounting Brackets
Allen Wrench

Installation Instructions

Dynasty Hardware
7500 Series Bath Hardware

Tools Needed:

Pencil
Stud Finder
Level
Electric or Cordless Drill
1/4" Drill Bit
Screw Driver

** When installing towel bars or toilet paper holders place the hardware on a flat surface as if it were mounted on the wall measure the exact distance between the center of one set screw to the center of the other set screw. The distance between the set screws is the distance you should use to install the mounting brackets on the wall. This dimension will be from the center of one bracket to the center of the other bracket.

- 1) Position the mounting bracket on the wall at the desired location for your new hardware. Using a pencil mark the location of the holes for the mounting bracket on the wall. Try to mark exactly in the middle of each hole in the bracket. When installing towel bars or toilet paper holders use a level to insure the marks on the wall are at the same height so the hardware will be mounted level.
- 2A) Use a stud finder to determine if you are mounting directly over a stud. If mounting directly over a stud in the wall drill small pilot holes and attach the mounting bracket using just screws. After Attaching bracket skip to step 5. **If you are installing into a hollow wall move on to step 2B.
- 2B) Drill two holes using a 1/4" diameter drill bit at the two pencil marks on the wall.
- 3) Insert the two plastic anchors into the holes.
- 4) Hold the mounting bracket over the anchors and line up the holes in the bracket with the holes in the anchors. Insert the screw and tighten with a hand held screw driver.
- 5) Loosen the set screw at the bottom of the hardware. Carefully slide the hardware over the mounting bracket.
- 6) Carefully tighten the set screw to secure the hardware to the wall.

